



## How to set 5V pulse signal output

### Descriptions

5V pulse output is mainly for planting trees scene which can output signal to terminal devices and also can mark/display some information in the GNAV3.0 software, this feature is mostly based on AB line and A+ line as well.

Also with the extra adaptive cable(PN: 4103020151) to connect to tablet Port3, then the these 2pin can be connected to terminal devices with outputting the signal.



Lateral deviation limit	0.10	m
Operation line (area) numbers	11	
Turn alignment	<input type="checkbox"/>	
Work area limit	<input checked="" type="checkbox"/>	
Distance from the headland	5.0	m
End point output switch	<input type="checkbox"/>	

[Apply](#)

**Signal output switch:** The switch to turn it/off the 5V pulse signal.

**Signal output type:** It includes Transplanter and Seeder these two types, 5V pulse signal advanced settings can be edited only after select the Seeder.

**Signal spacing:** The distance interval of outputting 5V pulse signal

**Signal turning on duration:** The duration of outputting the 5V pulse signal

**Lateral deviation limit:** Keep output 5V signal output within the tolerance of auto driving away the guidelines

**Operation area numbers:** Every area with one interval as one operation number which is only used when turn on the **Work area limit** option.

**Turn alignment:** Keep the same output as the first guideline on other guidelines.

**Work area limit:** Set the area close to headland where not output the signal.

**Distance from the headland:** The distance from start point or end point when set the **Work area limit**.

All guidelines take point A as the starting point of the operation, and then calculate the position of the end point based on the **Operation area numbers**.


**End point output switch:** Output the signal at the end point when set the **Work area limit**.

## Basic steps


1. Go to **System Setup**---**Port settings**---**Signal input/output settings**,



2. Turn on **Signal output switch** and select the **Seeder** in the **Signal output type**, then set the **Signal spacing**, finally click **Apply** to configure all of them.



- It will skip to main menu automatically, it is able to click Start output this icon to start output after start auto steering and take to the line.





## **CHC Navigation**

Building C, 577 Songying Road, Qingpu, District,  
201702 Shanghai, China

Tel: +86 21 542 60 273 | Fax: +86 21 649 50 963

Email: [sales@chcnav.com](mailto:sales@chcnav.com) | [support@chcnav.com](mailto:support@chcnav.com)

Skype: chc\_support

Website: [www.chcnav.com](http://www.chcnav.com)

Shanghai Huace Navigation Technology Ltd.  
Building C, 577 Songying Road, Qingpu, District,  
201702 Shanghai, China

WWW.CHCNAVCOM  
Tel: +86 21 54260273  
Stock Code:300627