How to export Farm, Field, guidelines and boundary

Here is the flow-process diagram of new farm and field logic

![CHCNAV]

Steps

1. Click **Farms** to go to farm list, there is a default farm, it is able to export farms.

2. Select the farms what users want to export, then export it.

CHCNAV

3. Go to CHCNAV---AGNAV3.0---SHP Export---Farm folder to check the farms what exactly export.

4. Regarding to the fields export, it is same procedure like farms, then go to CHCNAV---AGNAV3.0---SHP Export---Field folder to check the fields what exactly export.

5. Also go to Detail, then it is able to export boundary SHP and Guidelines SHP files, finally they can be found in CHCNAV---AGNAV3.0---SHP Export---Boundary/NavLine folder

Shanghai Huace Navigation Technology Ltd.
Building C, 577 Songying Road, Qingpu, District,
201702 Shanghai, China

WWW.CHCNAVCOM
Tel: +86 21 54260273
Stock Code:300627

CHC Navigation

Building C, 577 Songying Road, Qingpu, District,
201702 Shanghai, China

Tel: +86 21 542 60 273 | Fax: +86 21 649 50 963

Email: sales@chcnav.com | support@chcnav.com

Skype: chc_support

Website: www.chcnav.com